

Care & Operation of your New 26 LED Light

CAUTION

- 1. Inspect cord regularly for damage and replace if necessary for user safety.
- 2. Do not submerge.
- 3. When hanging reel models on ceiling:
 - -By Hook: Close hook with pliers to prevent reel from coming down. -By Bracket Pin: With reel in place, bend end of "L" shaped pin to prevent pin falling out.
 - -Read mounting instructions carefully before installing.
- 4. Use in covered areas out of rain and weather.
- Do not use in applications where liquid can run into or find its way into the face of the LED lamp.



OPERATION & MAINTENANCE

- 1. Plug the unit into a 120 VAC outlet. The power supply cord is UL listed and meets OSHA standards.
- 2. Disconnect the power supply before servicing.
- Keep the unit free from grease and dirt by using a damp cloth with mild detergent or waterless hand cleaner.
- Do not use solvents such as gasoline to clean unit or cord as it makes the parts brittle.

RELAMPING INSTRUCTIONS

- Step I Step II
- Disconnect the power supply (unplug). Unscrew lamp from socket by turning counter-clockwise while holding handle.
- Reverse steps I-II. Relamping finished. Step III

Note: We recommend you use ONLY original replacement parts.



| Item | Part No. | Description | Qty Required |
|------|-----------|---|--------------|
| 1 | 5000-2178 | 26 LED Lamp 120 volt | 1 |
| 2 | 5000-0743 | Handle-26 LED - side 1 (w/ switch hole) | 1 |
| 3 | 5000-0744 | Handle-26 LED - side 2 | 1 |
| 4 | 5000-0745 | Lamp socket | 1 |
| 5 | 5000-0748 | Screw, Handle (incl. w/ no. 2) | 3 |
| 6 | 5000-0746 | Switch Assembly w/ Rubber Boot | 1 |
| 7 | 5000-0400 | Connector, closed end, Insulated | 5 |
| 8 | 5000-0747 | 8" Nylon tie (strain relief) | 1 |
| 9 | 5000-6166 | Cord assy. 20' 18/2 SVT, yellow | 1 |
| | 5000-6167 | Cord assy. 50' 18/2 SJTOW, yellow | 1 |
| 10 | 5000-6168 | Reel assy. 50' 18/2 SVT, yellow | 1 |
| 11 | 5000-0801 | Cord hook, 18/2 SVT | 1 |
| | 5000-0811 | Cord hook, 18/2 SJT | 1 |
| 12 | 5000-0453 | Bail Hook | 1 |

CAUTION, IMPORTANT SAFETY INSTRUCTIONS - This

portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use an extension cord unless plug can be fully inserted. Do not alter the plug.

"ATTENTION, INSTRUCTIONS IMPORTANTES DE

SÉCURITÉ Cette lampe portative a une fiche polarisante (une lame est plus grande que l' autre) comme caracteristique pour reduire le risque de choc electrique cette fiche n' engage q' une prise polarisante. Si la fiche n' engage pas completement la prise, alors renverser la, si elle n' engage toujours pas, metter vous en rapport avec un electricien qualifie. Ne jamais utiliser avec un prolongateur si la fiche n' engage pas completement . Ne changer pas la fiche."

90 Day Warranty

This worklight was thoroughly tested and inspected and found to be in perfect working order before leaving our factory. If within 90 days from the date of purchase, any part of this unit proves to be defective in material or workmanship, such defective parts will be repaired or replaced (company option) free of charge. The company's liability in all events is limited to the purchase price paid.

The individual LED's are warranted for one year against defects in workmanship and material. The warranty does not apply to damage from power surges, connection to wrong power source alteration, misuse or abuse, not attribute to the manufacturer, representatives, dealers, or their employees.

Illustrations and descriptions are for the sole purpose of identification and do not express or imply a warranty that the products will necessarily conform to the illustrations or descriptions.

When returning product for warranty repair, please provide: from whom purchased, date of purchase, attached receipt or invoice number.

KEEP THIS MANUAL

If this Worklight malfunctions or is in need of repairs, send to: GENERAL MANUFACTURING, INC. 1100 S. MORGAN ST. BLUFFTON, IN 4674 PHONE: (260) 824-3440 FAX: (260) 824-3448 DO NOT return to place of purchase, they are not authorized to accept used or damaged units.

FORM # 9032-7159 (06-09-05)